

BREAKFAST CABINET ASSEMBLY INSTRUCTIONS

CC&Co

Breakfast cabinet 1922 mm dimensions



ORDER INSTRUCTION/The needed goods for a ready package:


Cabinet width		M70	M80	M90	M100
TOP	Frame	Code: KRO06 ROLLER-DOOR CABINET M6 1212*600*560	Code: KRO07 ROLLER-DOOR CABINET M7 1212*700*560	Code: KRO08 ROLLER-DOOR CABINET M8 1212*800*560	Code: KRO09 ROLLER-DOOR CABINET M9 1212*900*560
BOTTOM	Frame	Code: A06PR L. CABINET 710*600*560 Drawers and accesories need to be added.	Code: A07PR L. CABINET 710*700*560 Drawers and accesories need to be added.	Code: A08PR L. CABINET 710*800*560 Drawers and accesories need to be added.	Code: A09PR L. CABINET 710*900*560 Drawers and accesories need to be added.
DOORS	Measure	1920*296 Drilling 130/8 3 hinges (130/8 + middle)	1920*346 Note! Special measure Drilling 130/8 3 hinges (130/8 + middle)	1920*396 Drilling 130/8 3 hinges (130/8 + middle)	1920*446 Note! Special measure Drilling 130/8 3 hinges (130/8 + middle)
RAIL SET		Code: AAMIAISKAAPPI KISKOT BREAKFAST CABINET RAIL SET 1922 mm HIGH	Code: AAMIAISKAAPPI KISKOT BREAKFAST CABINET RAIL SET 1922 mm HIGH	Code: AAMIAISKAAPPI KISKOT BREAKFAST CABINET RAIL SET 1922 mm HIGH	Code: AAMIAISKAAPPI KISKOT BREAKFAST CABINET RAIL SET 1922 mm HIGH

NOTE! We recommend the use of cover panels on both sides of the cabinet.

The Rail Set includes:

- FOLDING DOOR MACHANISM DZ1319-0055 2 pairs
- FOLDING DOOR MACHANISM KIT DZ1316-0055 2 pairs
- METAL ROD 2 m DZ61040 2 pcs
- BREAKFAST CABINET TEMPLATE / RISER BLOCK 1 set
- HOLE PLUG WHITE Ø36 mm 6 pcs
- PANEL/BEAM 1835x60x16 MEL WHITE 2 pcs
- HINGES SLIDE-ON 107 CO X-P + HINGE PLATE SLIDE-ON KO EUROR. 6 pcs

Breakfast cabinet 1212 mm dimensions



ORDER INSTRUCTION/The needed goods for a ready package:

Cabinet width		M70	M80	M90	M100
TOP	Frame	Code: KRO06 ROLLER-DOOR CABINET M6 1212*600*560	Code: KRO07 ROLLER-DOOR CABINET M7 1212*700*560	Code: KRO08 ROLLER-DOOR CABINET M8 1212*800*560	Code: KRO09 ROLLER-DOOR CABINET M9 1212*900*560
	Door measure	1206*346	1206*396	1206*446	1206*496
	Note! Special measure Drilling 130/8	Note! Special measure Drilling 130/8	Note! Special measure Drilling 130/8	Note! Special measure Drilling 130/8	Note! Special measure Drilling 130/8
BOTTOM	Frame	Code: A07PR L. CABINET 710*700*560	Code: A08PR L. CABINET 710*800*560	Code: A09PR L. CABINET 710*900*560	Code: A10PR L. CABINET 710*1000*560
	Middle panel	Code: B7OVA MIDDLE PANEL 668x539 M70 Drawers and accesories need to be added.	Code: B8OVA MIDDLE PANEL 768x539 M80 Drawers and accesories need to be added.	Code: B9OVA MIDDLE PANEL 868x539 M90 Drawers and accesories need to be added.	Code: B10OVA MIDDLE PANEL 968x539 M100 Drawers and accesories need to be added.
	Door measure	137/278/350*696, 703*346	137/278/350*796, 703*396	137/278/350*896, 703*446	137/278/350*996, 703*496
RAIL SET	Code: AAMIAISKAAP. KISKOT 2 BREAKFAST CABINET RAIL SET 1212 mm HIGH	Code: AAMIAISKAAP. KISKOT 2 BREAKFAST CABINET RAIL SET 1212 mm HIGH	Code: AAMIAISKAAP. KISKOT 2 BREAKFAST CABINET RAIL SET 1212 mm HIGH	Code: AAMIAISKAAP. KISKOT 2 BREAKFAST CABINET RAIL SET 1212 mm HIGH	


The Rail Set 2 includes:

- FOLDING DOOR MACHANISM DZ1319-0055 2 pairs
- FOLDING DOOR MACHANISM KIT DZ1316-0055 2 pairs
- METAL ROD 2 m DZ61040 2 pcs
- BREAKFAST CABINET TEMPLATE / RISER BLOK 1 set
- HOLE PLUG WHITE Ø36 mm 4 pcs
- PANEL/BEAM 1123x60x16 MEL WHITE 2 pcs
- HINGES SLIDE-ON 107 CO X-P + HINGE PLATE SLIDE-ON KO EUROR. 4 pcs

NOTE !

- We recommend the use of cover panels on both sides of the cabinet
- Breakfast cabinet 1212 mm, is also available as pre-assembled, as shown in picture 21.
Code: AAMIAISKAAPINKASAUS

1.



1. Assemble the cabinet frame and drill adjustment holes for the hinges (diameter 35-35mm). Leave the uppermost shelf unattached.


- full height cabinet (1922 mm) - see dimension drawing 1.1.
- half height cabinet (1212 mm) - see dimension drawing 1.2.

2.



2. Place the penetration sleeves in position (4-6 pieces).

3.



3. Connect the tooth rail to the main rail (x4). The corner brackets included are unnecessary in this model.

4.




4. Position the fastening hooks correctly and tap them into place with a hammer.

5.



5. Rails ready for installation.

6.




6. Attach the rail to the beam with one screw where the screw markings are ready.

7.




7. Ensure that the rail is at a right angle to the beam and attach the remaining screws.

8.




8. Install the hinge plate in place. Ensure the orientation of the hinge plate from the picture.

9.




9. Install the mounting blocks around the Synchron wheel.

10.



10. The Synchron wheel with a hole on the left side of the image should go to the top of the cabinet.

11.



11. Place the Synchron wheel in the designated position on the rail.

12.



12. Attach the Synchron wheel to the rail using the screws provided in the rail package.

13.



13. Cut the metal rod to the correct length:

- for a full-height cabinet (height 1922 mm), the length of the rod = 1890 mm
- for a half-height cabinet (height 1212 mm), the length of the rod = 1180 mm

14.



14. Insert the metal rod into place and ensure that the wheels are aligned with each other.

15.



15. Attach the central support to the midpoint of the beam.

16.



16. Rail package ready.

17.



17. Place the template/riser block between the cabinet front edge and the bottom and top with the floor and ceiling.

18.



18. Drill 2 mm markings for the screws.

19.



19. Align the holes of the riser block and rails with the markings.

20.



20. Attach the riser block and rail to the side of the cabinet with 20 mm wood screws (4 pcs/rail). DO NOT ATTACH THE RAIL FROM THE FIRST HOLE OF THE FRONT EDGE!

21.



21. Rails installed in the cabinet.

22.



22. Attach the hinges to the hinge plates.

23.



23. Finally, attach the doors to the hinges.

Assemblies ready



1922 mm high Breakfast Cabinet



1212 mm high Breakfast Cabinet

Finished Breakfast Cabinet 1212 mm



Finished Breakfast Cabinet 1922 mm

